

Before you start

This Driver operates with the Windows Mobile 5 Operating System for Pocket PC.

Check that the Fabric Keyboard has power. The Fabric Keyboard requires 2 x AAA batteries (supplied):

1. Remove the slide-on cover on the Fabric Keyboard
2. Insert 2 x AAA batteries in the correct orientation into the battery compartment
3. Replace the slide-on cover

Installing the Driver

Your PDA requires a Driver in order to connect to and operate with the Fabric Keyboard. To install the Driver:

*Installation via **ActiveSync**:*

1. Ensure ActiveSync is installed on your PC before starting
2. Insert the supplied Fabric Keyboard CD into your PC
3. Connect the PC to your PDA using ActiveSync
4. From the CD, run the application called '**FabricKeyboard.exe**'
5. Follow the on-screen prompts displayed on the PC and then on the PDA
6. You may be required to restart your PDA to complete the installation

*Installation via **InfraRed** or **Bluetooth**:*

1. Insert the supplied Fabric Keyboard CD into your PC
2. Transfer the file '**FabricKeyboardPPC2005.arm.cab**' from the CD to your PDA via a Bluetooth or InfraRed connection
3. Install the file on the PDA by running it from its location (the default location for transferred files is '**My Documents**')
4. Follow the on-screen prompts displayed on the PC and then on the PDA
5. You may be required to restart your PDA to complete the installation

Installation is now complete. The 'Fabric Keyboard**' application will appear in the '**Programs**' section under '**Start Menu**'.**

Connecting to the Fabric Keyboard

To connect the Fabric Keyboard to your PDA:

1. Ensure the target device Bluetooth is ON, previous keyboard partnerships are deleted and the keyboard driver is installed.
2. Turn on keyboard (and wait for green flashing light to remain on constantly).
3. On the PDA navigate to the Bluetooth connection settings and select devices, then **new partnership**.
4. Wait for searching to finish and the '**keyboard**' to be found.
5. Select '**keyboard**' and then enter the **passcode 0000**.
6. Select '**serial port**' service if this is offered/requested by the PDA. When prompted to select 'serial port' service, tap refresh to make sure that the PDA is pairing to the right keyboard, then select 'serial port' service.
7. If the device needs to have a COM port set, then select '**new Outgoing Port**' and assign a free com port to the Keyboard e.g. com 8 (if possible, de-select the secure connection option to improve connection reliability).

8. Once the above is done, then navigate to the keyboard front/main page (using the shortcut on the programs page).

9. Select **Connect** from the keyboard front page and wait for the connection to be made or the Bluetooth devices page to come up (if the BT devices page comes up, then refresh this page and select the **'keyboard'** device).

Note: Before you tap connect make sure that the LED on the keyboard is ON constantly and **WAIT** for 10-15 seconds.

If the LED on keyboard has gone OFF before tapping **'connect'**, then check the partnership on Bluetooth connection settings, turn the LED on the keyboard back ON and **WAIT** for 10-15 seconds before **'connecting'**

10. Once the above is done wait for the connection to be made and then all is done.

11. Please note that it is necessary to wait for 10-15 seconds every time you want to re-connect to PDA.

You are now almost ready to use your device. However, before you do there are some important settings that should be done that are accessed from the **Options** tab from the Keyboard front page.

Important: During the pairing process, the keyboard may power down after a minute if no pairing has been established. If this happens power up the keyboard again (by pressing the power switch until the indicator light comes on steady) and continue (you may need to re-connect or search for Bluetooth devices again)

If connecting to a different keyboard to one previously connected, it is suggested that before pairing is attempted, the keyboard application is quit, Bluetooth is turned OFF and then ON again. Also, should you change your keyboard a new pairing will need to be established.

Connection is now complete. Follow the on-screen prompts to perform a calibration (this is recommended, see User Guide for details)

Troubleshooting

PDA will not pair with the Fabric Keyboard?

- Check that the PDA's Bluetooth is ON from the **'Bluetooth Manager'**
- Check that the Fabric Keyboard is ON and in pairing mode (the green light should be on constantly)
- From the Bluetooth console, where Bluetooth devices are displayed, perform a **'Refresh'** before selecting **'keyboard'**

The characters appearing on screen are not as typed?

- Perform a calibration. From the Fabric Keyboard application select **'Options'** > **'Calibration'** > **'Start Calibration'** and follow the on-screen instructions

Bluetooth will not turn ON within the PDA menu?

- Power cycle the PDA (turn the device OFF and then back ON again) or perform a soft reset



©2007 by Mobis Technology Ltd. All rights reserved. No part of this start guide may be reproduced, copied or translated in any form or by any means without prior written consent from Mobis Technology Ltd.

The content of this start guide is subject to change without prior notice. Mobis Technology Ltd. is not liable for any damages resulting from changes to this start guide. However, updates to this documentation can be obtained from the following website: <http://www.just-mobileonline.com>

Just Mobile® is a trademark of Mobis Technology Ltd. All other brand names used in this document are registered trademarks of their respective companies

Disclaimer: Mobis shall not be liable for any direct, indirect, consequential, or incidental damages (including damages from loss of business profits, business interruption, loss of business information, and the like) arising out of the use or inability to use the Just Mobile product even if Mobis has been advised of the possibility of such damages. The Just Mobile product is provided 'as is'. Mobis does not make any warranty of any kind, either expressed or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose.